







Montage- und Gebrauchsanweisung / Operating and assembly instructions Instructions de montage / Istruzioni di montaggio e d'uso

CE Ineoline Plus Typ: LD0.0008., LD0.0081., LD1.0051, LD1.0061., LD2.0002., LD2.0102., LD2.0202.





1. Stückliste / Parts list / de pièces détachées / Lista pezzi di ricambio




Toleranz - Länge in mm - Winkel in Grad °
Tolérance - longueur en mm - angle en degrés °
Tolleranze - lunghezza in mm - angolo in gradi °


Toleranzklasse	über 120 bis 400	über 400 bis 1000	über 1000 bis 2000
f (fein)	± 0,20	± 0,30	± 0,50
m (mittel)	± 0,50	± 0,80	± 1,20
g (grob)	± 1,20	± 2,00	± 3,00
sg (sehr grob)	± 2,50	± 4,00	± 6,00




2. Planungshilfe / Planning aids / Aide à la planification / Ausilio per la progettazione


















3. Montage / Installation mounting / montage / montaggio



4. Montagereihenfolge / Mounting order / suivre les instructions de montage / la sequenza di montaggio







5. Pflege und Reinigung / Cleaning and care / Entretien et nettoyage / Cura e pulizia

